ORBIT
WALLET

USER MANUAL

TABLE OF CONTENTS

WHAT IS ORBIT WALLET?

The Orbit Wallet is a stylish and handy fashion accessory, a definite must have for all men. This genuine leather wallet will charge your phone with ease. No need to carry around any cables as all cords are built in. iPhone and Android phones will both benefit from this wallet as it features a Micro-USB and iPhone adapter (included). The battery has a capacity of 2500mAh, enough to almost fully recharge your smartphone.

The Orbit Wallet also features 4 credit card slots with RFID blocking technology, a compartment for bills and tickets and a slot for receipts. Even though it contains a battery that charges your phone, the Orbit Wallet remains slim and lightweight, maintaining its classy and elegant appearance.

If you've ever misplaced your wallet, the Orbit Wallet has you covered. With a built in Orbit item finder, you will never lose your wallet again! Via the free Orbit app, you can make your wallet ring if within range (up to 100feet/30m), if out of range, you can check the map for your wallets last known location and time. You can also find your phone with your wallet. Press the button located on the battery to make your phone ring - even when it's silent. With the Orbit Wallet, you can take selfies. No need for a selfie stick, all you need to do is set your smartphone camera where you want it and with a click of the button on the battery, you can take selfies to your hearts content.

CONTENTS AND COMPATIBLITY

Orbit Wallet Index

Micro-USB cable

LED Battery life indicator
(1= Low, 4= Full)

Battery button (used to
activate, take selfie and find
phone)

iPhone adapter (connected
through Micro-USB)

USB cable used to charge battery

Charging the Battery

Charging the battery on your
Orbit Wallet is really easy.
Simply plug the USB cord into
a USB port (computer or wall
charger) and wait until the 4
LED lights on your battery light
up.

Charging the your phone with
the Orbit Wallet is even easier.
Simply plug the Micro-USB or
iPhone adapter cord into your
phone.

Mobile Device Compatibility

ORBIT syncs with the following devices that support Bluetooth 4.0:

iOS   **Android**

iPhone 5 or above   Android 4.4 or later

Made for iPhone

ORBIT WALLET FEATURES

Orbit Wallet

The ORBIT wallet is beautifully designed and crafted by HButler. With style and practicality in mind, the ORBIT wallet brings you everything you need when you're on the go. Containing not only a battery, but also a built in bluetooth locator known as the ORBIT. Never lose your wallet or phone again with this handy feature.

Genuine Leather

Built from 100% genuine leather, the Orbit wallet also features a unique, leather-lined bill slot, and 4 RFID blocking card slots. Finished with folded edges and a classic simplistic design, this leather wallet will become a useful necessity for years to come.

RFID Blocking

As fears of RFID hacking spread, The ORBIT Wallet offers you peace of mind without compromising design or style. With the latest in RFID blocking technology, all your personal cards will be safe from skimming in the ORBIT Wallet.

Compartments

The ORBIT Wallet was designed to be as fashionable as possible without sacrificing practicality and functionality. The ORBIT Wallet contains 4 credit card slots, a receipt slot and a bill fold with enough room for the usual essentials you need to carry every day.

Slim Profile

Although the ORBIT Wallet contains a 2500mAh battery, it still remains thin and practical. The slim profile was designed to fit in your pocket with ease just like a your every day wallet.
Wallet Thickness: 1.5cm (0.6inch)

BATTERY FEATURES

ORBIT Battery

The ORBIT wallet has a powerful 2500mAh battery capable of giving a your smartphone one full charge. Still slim enough to look and feel like a regular wallet. It features an LED Battery Life Indicator which reminds you how much charge you have left.

Built In Cables

There is no need to carry around charger cables anymore, the ORBIT Wallet does that for you. It contains a built in USB cable (used to recharge your battery), Micro-USB (used to charge your Android device) and an iPhone lightning adapter (used to charge Apple devices). The stylish braided cables not only give your wallet an interesting visual touch, but also tuck away nicely when they are not in use.

Adapters

We understand that not everyone is the same, that's why we made sure that the ORBIT Wallet caters to everyones needs. No matter what smartphone you own, you can charge up with the ORBIT Wallet. If you have an iOS device (iPhone 5 and later), attach the Apple adapter to the end of the Micro-USB, if you have an Android device just detach the Lightning adapter.

Charge Reminder

When your phone is about to die, the Orbit Wallet is your best friend. But imagine trying to charge up with your new ORBIT Wallet, only to find that you forgot to recharge it the night before. The charge reminder function eliminates this nightmare. As you set up your ORBIT Wallet, make sure to turn on the 'Charge Reminder' setting. As you step in your house (using location settings) you will receive a notification reminding you to recharge your ORBIT Wallet if the Orbit Wallet battery is below 30%.

ORBIT FEATURES

Find Your Phone

After connecting the Orbit Wallet to your phone, you will now be able to locate your phone using the Orbit Wallet. If you have misplaced your phone, press the button on your Orbit Wallet battery and listen out for your phone to ring, even if it's on silent. Your phone will need to be within Bluetooth range (up to 100ft/30m)

Find Your Wallet

You can now also find your Orbit Wallet with your phone. If you have misplaced your wallet, tap 'Find Orbit' on the Orbit App and listen out for your Orbit Wallet to ring. If your Orbit Wallet is out of the 100ft/30m radius, the last seen location will be shown on the app.

Separation Alarm

Turning on the Separation Alarm allows for your Orbit and your phone to both ring when the devices step out of the 100ft/30m radius to notify you that you have forgotten an item.

Selfie Remote

Tap on the top right icon at the top of the toolbar. Position/focus your phone to what you want to take a photo of. Click the button located on the battery of your ORBIT Wallet to take the photo. Pictures taken can be found in your phones gallery. When finished, tap on the arrow in the bottom left corner on the app. Please note: You must use the camera in the app to use the selfie function with Orbit.

Last Seen Location

If you are separated with the Orbit Wallet past a distance of 100ft/30m, the last seen location will be saved. Pressing 'Find Orbit' on your map will not work if you are further than the 100ft/30m range. Go to the last seen location (shown on the map). Once you are in the 100ft/30m radius, the Orbit Wallet will ring once again.

GETTING STARTED

Downloading the App

Head to the App Store or Google play and download "ORBIT" by HButler.

ORBIT

Open the app, and allow for the app to find your location. Please ensure bluetooth is turned on for the app to connect to your Orbit Wallet.

Settings

Device List

Camera

SIGNAL

DISTANCE

93 %

NEAR

CONNECTION

BATTERY

CONNECTED

100 %

FIND ORBIT

Find ORBIT

How to Connect your ORBIT Wallet to your Phone

Initially to activate your Orbit Wallet, hold down the button on the battery for 5 seconds.

Tap the Orbit icon (located in the top left corner of the home screen).

Tap on the (+) icon to add device. "ORBIT" will appear in the list. Your Orbit wallet should now be synced to the app.

How to Rename ORBIT

Tap on the top right "Edit" button. If you have more than one device synced, make sure to select the correct device when changing names.

Tap on the name of the device and rename it accordingly. Don't forget you can buy other Orbit products and sync them all to the same app!

How to Disconnect an ORBIT device

Tap on the device you want to disconnect. now Swipe right on the name and the Delete box will appear.

How to add Multiple ORBITs

Tap on the (+) icon to add another device. Searching will begin and once found, the "ORBIT device" will appear in the list. Rename it to keep track of which one is which. This will help when searching for your device. Make sure the one you want to find is highlighted by tapping it.

HOW TO USE THE ORBIT APP

How to Locate ORBIT

All of the Orbit products work almost identical and can all be connected with the same app. Tap on the "FIND ORBIT" button at the bottom of the home screen. Your Orbit will ring if it's within range. If there is no ring, a notification will appear with the last known location of your Orbit.

Signal:
Shows how close you are from your Orbit

Distance:
Will indicate if you are Near, Medium, or Far from your Orbit

Connection:
Will notify you if you are connected or disconnected

Battery:
Shows you how much charge your Orbit has left

SIGNAL **93** % DISTANCE **NEAR**

CONNECTION **CONNECTED** BATTERY **100** %

FIND ORBIT

How to Locate Your Phone

Press the side button on the battery, and your phone will ring and flash* if it within range.
If there is no ring, the phone is out of range. This function also works if the app is not running. However, it can take a few minutes for the Orbit to connect to your phone in this case.

Battery button

How to take a selfie with your wallet

Tap on the camera icon in the top right corner. Position or place your phone anywhere, get in the shot and click the battery button to take a photo. Your wallet is now a selfie remote! All photos will be stored in your gallery. Please note that this only works with the camera in the app.

Advanced Settings

Tap on the settings button in the middle.
General settings include Separation Alarm and Safe Zone settings.

Separation Alarm

Turning on the Separation Alarm allows for your Orbit and your phone to both ring when the devices step out of the 100ft/30metre radius to notify you that you have forgotten an item.

Safe Zone

If the Safe Zone feature is turned on, the Separation Alarm will not work when connected to wifi. This feature is perfect for when you're at home around the house.

Charge Reminder

Turn Charge Reminder on when in the WIFI zone you want to be reminded to charge your wallet. Charge reminder will send you a notification when your phone connect to the selected WIFI and if your wallet battery is below 30%, reminding you to charge your Orbit Wallet.

Ringtones

There are over 15 ringtone alarms to choose from. Select a melody that suits you. Select a different ringtone for different Orbits.

SUPPORT

Orbit Technology and Tech Details:
Orbit uses Bluetooth Low Energy (BLE) technology to help you locate your items. While Bluetooth technology is a wireless technology, there are significant differences between Bluetooth, Wi-Fi, and GPS technology. Orbit's Bluetooth range is up to 100 ft. Bluetooth is most effective at the 30ft range, depending on the environment. Learn more about Bluetooth at http://www.bluetooth.com/
Battery: 2500mAh Battery

Is my phone compatible with Orbit?
Orbit requires a phone to be running the Orbit app in the background. Bluetooth must be left on in the background (don't worry, our engineers have minimized the battery drain on your phone by leaving Bluetooth on). Orbit works with: iPhone 5 and later. and Android 4.4 or later
Bluetooth 4.0 or later is required

How many Orbit devices can be paired to my phone or tablet?
Apple iOs devices can pair up to 6 Orbit devices at a time. Android devices can pair anywhere between 1-3 depending on the manufacturer and the operating system version.

Can I use the Orbit on humans or my pet?
Orbit is meant to prevent and locate misplaced or stolen items. I'm sorry to say that we do not advise that Orbit should be used on people. We would recommend that you look into live GPS tracking services instead.

Warranty Procedure
If you are having any issues with your Orbit, please don't hesitate to email us at help@hbutler.co and a team member will help resolve any issues you're having with the product.

For more information please visit
www.findorbit.com/help

SPECIFICATIONS

Battery

The ORBIT Wallet contains a 2500mAh battery with built in USB, Micro USB cables and iPhone adapter. It will give 1x full charge on most smartphones (Newer smartphones on the market may require more power for a full charge). The battery has 4 LED lights indicating power levels, with 1 light being low power and 4 lights indicating high/full power. Once your battery goes below 30%, you will receive a reminder on your phone to recharge. Recharge your ORBIT wallet by inserting the USB cable into a wall charger or laptop until all 4 LED lights are lit. Please refer to page 3 for a diagram and more information.

Best practices to maximise ORBIT's battery life:
- Keep the app up to date
- Resist unnecessary tapping of ORBIT as a party trick

Operating temperature range: -22° to 14° F (-30° to 60° C)

Environmental Conditions
Operating temperature: -4° to 122° F (-20° to 50° C)

Return Policy and Warranty
ORBIT has a Six Months Limited Warranty - for more information, visit:
www.hbutler.co

Disposal and Recycling

Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle ORBIT and accompanying components. Do not dispose of ORBIT with common household waste, the ORBIT unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility. For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product. When discarding batteries, insulate the + and - faces of batteries with insulating or any kind of non-conductive tape [see diagram]. If improperly disposed, lithium batteries may short, causing them to become hot, burst or ignite.

IMPORTANT SAFETY WARNINGS

General Precautions

- ORBIT is not a toy
- Do not attempt to tamper with/modify/disassemble ORBIT
- Do not expose ORBIT to abrasive materials
- Do not place ORBIT near open flames
- Review ORBIT Specifications and other Information > Environmental Conditions and do not expose ORBIT beyond
   operating temperatures
- ORBIT's metal body conducts temperature effectively, avoid contact when left in extreme temperatures
- ORBIT's edges can be sharp, handle with care

Read, follow and keep this user manual and all safety instructions. Improper installation, use or disposale of ORBIT could be hazardous to your health and put others at risk.

Child Safety

ORBIT contains small parts, which can be a choking hazard. Please keep away from young children.
If battery is swallowed, immediately seek medical help as serious injury may occur.

Battery Precautions

- Do not charge, short, disassemble, deform or heat batteries
- Do not throw batteries into fire
- Avoid mixed use of batteries, e.g. new, used or different types
- Keep batteries away from direct sunlight, high temperature and humidity
- Keep batteries out of reach of small children. Should a child swallow a battery, consult a physician immediately.

REGULATORY NOTICES

North America

United States: Federal Communications Commissions [FCC]

FCC COMPLIANCE STATEMENT:
This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residentual installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna
-Increase the distance between the equipment and the reciever
-Connect the equipment to outlet on a circuit different from that to which the receiver is connected
-Consult the dealer or an experienced radio/TV technician for help

WARNING:
The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

European Union

European Union: CE directive

STATEMENT:
Hereby, HButler Pty Ltd, declares that Orbit is in compliance with the esstential requirements and other relevant provisions of Directive 1999/5/EC.

WEEE:

The symbol on the product or its packaging signifies that this product has to be disposed separately from ordinary houseold wastes at its end of life. Please kindly be aware that this is your responsibility to dispose electronic equipment at recycling centers so as to help conserve natural resources. Each country in the European Union should have its collection centers for electrical and electronic equipment recycling.

For information about your recycling drop off point, please contact your local related electrical and electronic equipment waste management authority or the retailer where you bought the product.

- Do not dispose of the Orbit with household waste.
- Disposal of the packaging and your Orbit should be done in accordance with local regulations.
- Batteries are not to be disposed of in municipal waste stream and require separate collection.